

Simple easy steps to install your new Prius front bra.



Step 1 – Locate both vinyl coated hooks above center grill. Attach hook(s) behind the corner of each grill under the hood.



Step 2 – Insert each tab(s) under each headlight towards corner.



Step 3 – Locate the 2 clip(s) under the front of each airdam and hook them into the bottom of the spoiler



Step 4, 5, 6 – Place the prebent hooks around the fender(s) of each wheel starting with the bottom one first.



Step 6 and 7 – Insert the the hood piece with the bungee shock cord towards the bottom. Pull the driver side bungee and attach hook to the hood prop flange. Pull the passenger side cord towards the bottom hole opening of the hood. (make sure to put the bungee cord above your windshield water line)

Thank you for your purchase, please keep your warranty card for future reference.